

# GIVI Walkaround for Africa Twin CRF1100

By Svetlana Evens

## What you need :

1. **GIVI** supplied Universal Fixture +



2. M4 screws Flathead 35mm



3. Cushion if wanted



---

Unscrew the bottom left and right hand and top (one) screws. Keep them **safe somewhere** 😊

Place the supplied Tankguard Tape on the universal Mounting ring, then place the Bashplate ring inside, make sure it sits in the gaps of the Mounting ring !

Put the screws through and screw the cushioning Tape through the screws and on the bottom of all.

Then just place the whole thing according to your inserts and fasten the screws.(If desired use some blue Loctite)



Full Turn 😊



Have Fun, and drive safely 😊 !